# M-BUS communication protocol

User manual

1MSUECMBS006

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

***Limitation of Liability***

*The Manufacturer reserves the right to modify the specifications in this manual without previous warning. Any copy of this manual, in part or in full, whether by photocopy or by other means, even of electronic nature, without the manufacture giving written authorisation, breaches the terms of copyright and is liable to prosecution.*

*It is absolutely forbidden to use the device for different uses other than those for which it has been devised for, as inferred to in this manual. When using the features in this device, obey all laws and respect privacy and legitimate rights of others.*

*EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL THE MANUFACTURER BE LIABLE FOR CONSEQUENTIAL DAMAGES SUSTAINED IN CONNECTION WITH SAID PRODUCT AND THE MANUFACTURER NEITHER ASSUMES NOR AUTHORIZES ANY REPRESENTATIVE OR OTHER PERSON TO ASSUME FOR IT ANY OBBLIGATION OR LIABILTY OTHER THAN SUCH AS IS EXPRESSLY SET FORTH HEREIN.*

*All trademarks in this manual are property of their respective owners.*

*The information contained in this manual is for information purposes only, is subject to changes without previous warning and cannot be considered binding for the Manufacturer. The Manufacturer assumes no responsabilty for any errors or incoherence possibly contained in this manual.*

# M-BUS communication protocol

**for M-BUS modules**

**for counters with integrated M-BUS interface**

October edition 2014

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

# INDEX


1. M-Bus interface ..... 9

1.1 Overview ..... 9

2. Telegram formats ..... 9

2.1 Telegram fields ..... 9

2.1.1 C Field ..... 10

2.1.2 A Field ..... 10

2.1.3 CI Field ..... 10

2.1.4 L Field ..... 11

2.1.5 CS Field (Checksum) ..... 11

2.2 Active data ..... 11

2.2.1 Coding of Active Data Transmitted From Slave to Master: Fixed Data Record Header ..... 11

2.2.2 Coding of Active Data Transmitted From Slave to Master: Data Records ..... 11

2.2.2.1 DATA INFORMATION BLOCK (DIB) ..... 12

2.2.2.2 VALUE INFORMATION BLOCK (VIB) ..... 12

2.2.2.3 STANDARD VALUE INFORMATION FIELD (VIF) USED ..... 13

2.2.2.4 STANDARD VALUE INFORMATION FIELD EXTENSION (VIFE) USED ..... 13

2.2.2.5 MANUFACTURER SPECIFIC VALUE INFORMATION FIELD EXTENSION (VIFE) USED ..... 13

3. Communication process ..... 15

3.1 Send / confirm procedure ..... 15

3.1.1 SND_NKE ..... 15

3.1.2 SND_UD ..... 15

3.1.2.1 SET PRIMARY ADDRESS ..... 16

3.1.2.2 SET SECONDARY ADDRESS ..... 16

3.1.2.3 SET BAUD RATE ..... 17

3.1.2.4 RESET TOTAL/TARIFF 1/TARIFF 2/ALL ENERGY COUNTERS ..... 18

3.1.2.5 RESET PARTIAL ENERGY COUNTERS ..... 18

3.1.2.6 START PARTIAL ENERGY COUNTERS ....19
3.1.2.7 STOP PARTIAL ENERGY COUNTERS ....20
3.1.2.8 SELECT A SLAVE USING SECONDARY ADDRESS ....20
3.1.2.9 SET PARAMETERS MASKS ....21
3.1.3 REQ_UD2 ....22
3.1.4 RSP_UD ....22
3.1.4.1 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED ACTIVE ENERGY, TOTAL ....23
3.1.4.2 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED ACTIVE ENERGY, TOTAL ....23
3.1.4.3 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED INDUCTIVE APPARENT ENERGY, TOTAL ....24
3.1.4.4 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED INDUCTIVE APPARENT ENERGY, TOTAL ....24
3.1.4.5 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED CAPACITIVE APPARENT ENERGY, TOTAL ....24
3.1.4.6 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED CAPACITIVE APPARENT ENERGY, TOTAL ....25
3.1.4.7 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED INDUCTIVE REACTIVE ENERGY, TOTAL ....25
3.1.4.8. 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED INDUCTIVE REACTIVE ENERGY, TOTAL ....25
3.1.4.9 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED CAPACITIVE REACTIVE ENERGY, TOTAL ....26
3.1.4.10 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED CAPACITIVE REACTIVE ENERGY, TOTAL ....26
3.1.4.11 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED ACTIVE ENERGY, TARIFF 1 ....27
3.1.4.12 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED ACTIVE ENERGY, TARIFF 1 ....27
3.1.4.13 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED INDUCTIVE APPARENT ENERGY, TARIFF 1 ....27
3.1.4.14 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED INDUCTIVE APPARENT ENERGY, TARIFF 1 ....28
3.1.4.15 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED CAPACITIVE APPARENT ENERGY, TARIFF 1 ....28
3.1.4.16 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED CAPACITIVE APPARENT ENERGY, TARIFF 1 ....28
3.1.4.17 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED INDUCTIVE REACTIVE ENERGY, TARIFF 1 ....29
3.1.4.18 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED INDUCTIVE REACTIVE ENERGY, TARIFF 1 ....29
3.1.4.19 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED CAPACITIVE REACTIVE ENERGY, TARIFF 1 ....30
3.1.4.20 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED CAPACITIVE REACTIVE ENERGY, TARIFF 1 ....30
3.1.4.21 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED ACTIVE ENERGY, TARIFF 2 ....30
3.1.4.22 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED ACTIVE ENERGY, TARIFF 2 ....31
3.1.4.23 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED INDUCTIVE APPARENT ENERGY, TARIFF 2 ....31
3.1.4.24 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED INDUCTIVE APPARENT ENERGY, TARIFF 2 ....31
3.1.4.25 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED CAPACITIVE APPARENT ENERGY, TARIFF 2 ....32
3.1.4.26 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED CAPACITIVE APPARENT ENERGY, TARIFF 2 ....32
3.1.4.27 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED INDUCTIVE REACTIVE ENERGY, TARIFF 2 ....33
3.1.4.28 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED INDUCTIVE REACTIVE ENERGY, TARIFF 2 ....33
3.1.4.29 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 IMPORTED CAPACITIVE REACTIVE ENERGY, TARIFF 2 ....33
3.1.4.30 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 EXPORTED CAPACITIVE REACTIVE ENERGY, TARIFF 2 ....34
3.1.4.31 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 VOLTAGE ....34
3.1.4.32 LINE 12, LINE 23 AND LINE 31 VOLTAGE ....34
3.1.4.33 3-PHASE, PHASE 1, PHASE 2, PHASE 3 AND NEUTRAL CURRENT ....35

3.1.4.34 FREQUENCY ..... 35
3.1.4.35 PHASE ORDER ..... 35
3.1.4.36 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 POWER FACTOR ..... 35
3.1.4.37 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 ACTIVE POWER ..... 36
3.1.4.38 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 APPARENT POWER ..... 36
3.1.4.39 3-PHASE, PHASE 1, PHASE 2 AND PHASE 3 REACTIVE POWER ..... 37
3.1.4.40 3-PHASE IMPORTED AND EXPORTED ACTIVE ENERGY PARTIAL ..... 37
3.1.4.41 3-PHASE IMPORTED AND EXPORTED INDUCTIVE APPARENT ENERGY PARTIAL ..... 37
3.1.4.42 3-PHASE IMPORTED AND EXPORTED CAPACITIVE APPARENT ENERGY PARTIAL ..... 38
3.1.4.43 3-PHASE IMPORTED AND EXPORTED INDUCTIVE REACTIVE ENERGY PARTIAL ..... 38
3.1.4.44 3-PHASE IMPORTED AND EXPORTED CAPACITIVE REACTIVE ENERGY PARTIAL ..... 38
3.1.4.45 3-PHASE ACTIVE ENERGY BALANCE ..... 39
3.1.4.46 3-PHASE INDUCTIVE AND CAPACITIVE APPARENT ENERGY BALANCE ..... 39
3.1.4.47 3-PHASE INDUCTIVE AND CAPACITIVE REACTIVE ENERGY BALANCE ..... 39
3.1.4.48 CT VALUE ..... 40
3.1.4.49 ACTUAL TARIFF ..... 40
3.1.4.50 SERIAL NUMBER ..... 40
3.1.4.51 MODEL ..... 40
3.1.4.52 TYPE ..... 41
3.1.4.53 ENERGY COUNTER FIRMWARE RELEASE 1 ..... 41
3.1.4.54 ENERGY COUNTER FIRMWARE RELEASE 2 ..... 41
3.1.4.55 ENERGY COUNTER HARDWARE RELEASE ..... 41
3.1.4.56 PRIMARY OR SECONDARY VALUE ..... 42
3.1.4.57 ERROR CODE ..... 42
3.1.4.58 OUT OF RANGE ..... 42
3.1.4.59 FABRICATION NUMBER ..... 42
3.1.4.60 M-BUS MODULE FIRMWARE RELEASE ..... 43
3.1.4.61 M-BUS MODULE HARDWARE RELEASE ..... 43
3.1.4.62 PARTIAL COUNTER STATUS ..... 43
3.1.4.63 FSA VALUE ..... 43

**ANNEX A ..... 44**

**ANNEX B ..... 44**

**ANNEX C ..... 46**

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

# 1. M-Bus interface

The M-BUS Interface (1 module wide, DIN rail mount) is developed to connect the Energy Counter to M-BUS.
The interface receives the measurement data from the Energy Counter using infrared port available on the side of the counter, and gets the power supply from the bus.

Energy counters with integrated M-BUS interface allows to transmits data directly in M-BUS network, to manage counter without need of external communication module.



## 1.1 Overview

- M-BUS Interface complying with EN13757-2 and EN13757-3
- Circuiting by means of drilled two-wires cables
- 2 screw clamps on M-BUS Interface
- Current consumption of M-BUS Interface: ≤ 3 mA. This corresponds to 2 standard loads.
- The data transmission speed is selectable between 300, 600, 1200, 2400, 4800 and 9600 baud
- The default speed is 2400 baud
- The default Primary Address is 000

# 2. Telegram formats

The telegram formats are three, identified by the first character.

| Byte | Single character (HEX) | Short Telegram (HEX) | Long Telegram (HEX) |
|---|---|---|---|
| 1 | E5 | 10 | 68 |
| 2 | | C Field | L Field |
| 3 | | A Field | L Field (Ripetition) |
| 4 | | CS (Checksum) | 68 |
| 5 | | 16 | C Field |
| 6 | | | A Field |
| 7 | | | CI Field |
| 8 - YY | | | Data (0 – 246 Bytes) |
| YY + 1 | | | CS (Checksum) |
| YY + 2 | | | 16 |

*Table 2.1 – The M-BUS Telegram Formats*

- **Single Character**: This telegram format consists of the single character E5h and is used to acknowledge the telegram received.
- **Short Telegram**: This telegram is identified by the start character 10h and consists of five character. It's used by the M-BUS Master to command the transmission of data from the M-BUS Slave.
- **Long Telegram**: This telegram is identified by the start character 68h and consists of a variable number of characters, in which are present also the active data. It's used by the M-BUS Master to transmits commands to the M-BUS Slave, and by the M-BUS Slave to send the read-out Data from the M-BUS Master.

## 2.1 Telegram fields

The telegram fields (C, A, CI Fields, L and CS) have a fixed length of one byte (8 bit) and serve predetermined effects in the M-BUS communication. The L Field defines the number of bytes of the active data.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 2.1.1 C FIELD

The Control Field (C Field) contains information on the direction of the exchange of communication, the success of the actual operation of communication and the proper function of the telegram.

| Bit Number | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|---|---|---|---|---|---|---|---|---|
| Master → Slave | 0 | 1 | FCB | FCV | F3 | F2 | F1 | F0 |
| Slave → Master | 0 | 0 | ACD | DFC | F3 | F2 | F1 | F0 |

*Table 2.2 – C Field Bit Division*

The Bit Nr 6 is set to 1 if the communication has the direction Master → Slave; viceversa it is set to 0.
In the Master → Slave direction, if the frame count bit valid (FCV - Bit Nr 4) is set to 1, then the frame count bit (FCB – Bit Nr 5) has not to be ignored.

The FCB is used to indicate successful transmission procedure. A Master shall toggle the bit after a successful reception of a reply from the Slave. After this, if the Slave answer is multi-telegram, the Slave has to send the next telegram of the multi-telegram answer.
If the expected reply is missing, or the reception faults, the master resends the same telegram with the same FCB.
The Bits Nr 3 – 0 are the function code of the message.
The C Field used here, are:

| Telegram Name | C Field (BIN) | C Field (HEX) | Telegram | Description |
|---|---|---|---|---|
| SND_NKE | 01000000 | 40 | Short Frame | Initialization of the Slave |
| SND_UD | 01x10011 | 53 / 73 | Long Frame | Master send data to Slave |
| REQ_UD2 | 01x11011 | 5B / 7B | Short Frame | Master requests Class 2 Data to Slave |
| RSP_UD | 000x1000 | 08 / 18 | Long Frame | Data transfer from Slave to Master |

*Table 2.3 – C Field of the commands used in this protocol*

### 2.1.2 A FIELD

The Address Field (A Field) is used to address the recipient in the calling direction, and to identify the sender of information in the receiving direction.
The size of this field is one byte, and it can assume the value between 0 – 255, divided in this way:

| A Field (HEX) | Primary Address | Remarks |
|---|---|---|
| 00 | 0 | Default Address Given by Manufacturer |
| 01 – FA | 1 – 250 | Primary Address Settable |
| FB, FC | 251, 252 | Reserved for Future Use |
| FD | 253 | Used for Secondary Address Procedures |
| FE | 254 | Use to Transmit Information to All Partecipants in the M-BUS System |
| FF | 255 | Use to Transmit Information to All Partecipants in the M-BUS System |

*Table 2.4 – Value of Address Field*

Using the address 254 (FEh) every Slave answer with the acknowledging (E5h) or with their primary address.
Using the address 255 (FFh) no one Slave replies.

### 2.1.3 CI FIELD

The Control Information (CI Field) contains information for the receiver of the telegram.
The CI Field values used here, are:

| CI Field (HEX) | Primary Address |
|---|---|
| 51 | The telegram contains data for the Slave |
| 52 | Selection of the Slave |
| 72 | The telegram contains data for the Master |
| B8 | Set Baud Rate to 300 bps |
| B9 | Set Baud Rate to 600 bps |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| CI Field (HEX) | Primary Address |
|---|---|
| BA | Set Baud Rate to 1200 bps |
| BB | Set Baud Rate to 2400 bps |
| BC | Set Baud Rate to 4800 bps |
| BD | Set Baud Rate to 9600 bps |
| BE | Set Baud Rate to 19200 bps |
| BF | Set Baud Rate to 38400 bps |

*Table 2.5 – Value of CI Field*



### 2.1.4 L FIELD

The Length Field (L Field) defines the number of bytes (expressed in hex value) of the Active Data making up the telegram, plus 3 byte for the C, A and CI Fields.
This field is always transmitted twice in Long Telegrams.

### 2.1.5 CS FIELD (CHECKSUM)

The Checksum (CS Field) serves to recognize transmission and synchronization faults, and is configured from specific parts of telegram. The checksum is calculated from the arithmetical sum of the data mentioned above plus the Active Data, i.e. from C Field to CS Field (excluded).

## 2.2 Active data

The Active Data (0 – 246 bytes) in Long Telegrams include the data to be read from the M-BUS Master (Read-Out Data), or Command Information transmitted by the Master to the Slave.

### 2.2.1 CODING OF ACTIVE DATA TRANSMITTED FROM SLAVE TO MASTER: FIXED DATA RECORD HEADER

Each block of Active Data transmitted by the Slave to the Master starts with the following Fixed Data Record Header (FDH):

| Byte Nr. | Size (Byte) | Value (Hex) | Description |
|---|---|---|---|
| 1 – 4 | 4 | xx xx xx xx | M-BUS Interface Identification Number |
| 5 – 6 | 2 | xx xx | Manufacturer's ID |
| 7 | 1 | xx | Version Number of M-BUS Interface Firmware (00 – FF) |
| 8 | 1 | 02 | Medium: Electricity |
| 9 | 1 | xx | Access Number (00 – FF → 00) |
| 10 | 1 | xx | M-BUS Interface Status (20 = Energy Counter Unreachable, 00 = Energy Counter Reachable) |
| 11 – 12 | 2 | 0000 | Signature (always 0000, i.e. not used) |

*Table 2.6 – Fixed Data Record Header*

The Identification Number is a changeable number by the customer and runs from 00000000 to 99999999.
The Access Number has unsigned binary coding, and is incremented (modulo 256) by one after each RSP_UD from the Slave.

### 2.2.2 CODING OF ACTIVE DATA TRANSMITTED FROM SLAVE TO MASTER: DATA RECORDS

Every Data Record sent by Slave to the Master consist of the following Data Record Header (DRH) :

| Data Information Block (DIB) | | Value Information Block (VIB) | | |
|---|---|---|---|---|
| DIF | DIFE | VIF | VIFE | Data |
| 1 Byte | 0 – 10 Byte(s) | 1 Byte | 0 – 10 Byte(s) | 0 – n Bytes |

*Table 2.7 – Data Records Structure*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

#### 2.2.2.1 Data Information Block (DIB)

The Data Information Block (DIB) contains as a minimum one Data Information Field (DIF). This byte can be extended by a further 10 Data Information Field Extension Bytes (DIFE).
The coding of DIF for this protocol is:

| Bit | Name | Description |
|---|---|---|
| 7 | Extension Bit | Specifies if a DIFE Byte follows:<br>0 = No<br>1 = Yes |
| 6 | LSB of Storage Number | Always at 0, i.e. not used |
| 5 - 4 | Functions Field | Specifies the kind of the value, always at:<br>00 = Instantaneous Value |
| 3 - 0 | Data Field | Length and Coding of Data:<br>0001: 8 Bit Integer<br>0010: 16 Bit Integer<br>0011: 24 Bit Integer<br>0100: 32 Bit Integer<br>0110: 48 Bit Integer<br>0111: 64 Bit Integer<br>1100: 8 digit BCD<br>1101: Variable Length |

*Table 2.8 – Data Information Field Structure*

The coding of DIFE for this protocol is:

| Bit | Name | Description |
|---|---|---|
| 7 | Extension Bit | Specifies if a DIFE Byte follows:<br>0 = No<br>1 = Yes |
| 6 | Unit | Specifies the kind of Energy or Power when Bit 7 is set to 1:<br>0 = Reactive<br>1 = Apparent |
| 5 - 4 | Tariff | Specifies which tariff the values are related:<br>00 = Total Value<br>01 = Tariff 1<br>02 = Tariff 2 |
| 3 - 0 | Storage Number | Always at 0000 |

*Table 2.9 – Data Information Field Extension Structure*

If Bit 7 is set to 0, the following Data Byte are related to Active Energy or Power. So, if the first DIFE is followed by another DIFE (i.e. Bit 7 is set to 1), the following Data Byte are related to Reactive or Apparent Energy or Power, depending on Bit 6 value.

#### 2.2.2.2 Value Information Block (VIB)

The Value Information Block (VIB) contains as a minimum one Value Information Field (VIF). This byte can be extended by a further 10 Value Information Field Extension Bytes (DIFE).
The coding of VIF is:

| Bit | Name | Description |
|---|---|---|
| 7 | Extension Bit | Specifies if a VIFE Byte follows:<br>0 = No<br>1 = Yes |
| 6 - 0 | Value Information | Contains Information on the single Value, such as Unit, Multiplicator, etc... |

*Table 2.10 – Value Information Field Structure*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

The coding of VIFE is:

| Bit | Name | Description |
|---|---|---|
| 7 | Extension Bit | Specifies if a VIFE Byte follows:<br>0 = No<br>1 = Yes |
| 6 - 0 | Value Information | Contains Information on the single Value, such as Unit, Multiplicator, etc... |

*Table 2.11 – Value Information Field Extension Structure*



#### 2.2.2.3 Standard Value Information Field (VIF) Used

| VIFE (BIN) | VIFE (HEX) | Description | Unit |
|---|---|---|---|
| 10000010 | 82 | Energy | 0.1Wh |
| 01111001 | 79 | Set Secondary Address | Dimensionless |
| 01111010 | 7A | Set Primary Address | Dimensionless |
| 10101000 | A8 | Power | mW |
| 11111101 | FD | A standard VIFE from extension table follows | Dimensionless |
| 11111111 | FF | A further manufacturer specific VIFE follows | Dimensionless |

*Table 2.12 – Standard Value Information Field Used*

#### 2.2.2.4 Standard Value Information Field Extension (VIFE) Used

| VIF (BIN) | VIF (HEX) | Description | Unit |
|---|---|---|---|
| 00001011 | 0B | Parameter Set Identification | Dimensionless |
| 00001100 | 0C | Firmware Version | Dimensionless |
| 00001101 | 0D | Hardware Version | Dimensionless |
| 11001100 | C6 | Voltage | mV |
| 11011001 | D9 | Current | mA |

*Table 2.13– Standard Value Information Field Extension Used*

#### 2.2.2.5 Manufacturer Specific Value Information Field Extension (VIFE) Used

| VIFE (BIN) | VIFE (HEX) | Description | Unit |
|---|---|---|---|
| 00000000 | 00 | 3-Phase | 0.1Wh, mV, mA, mW, mVA or mvar |
| 00000001 | 01 | Phase 1 | 0.1Wh, mV, mA, mW, mVA or mvar |
| 00000010 | 02 | Phase 2 | 0.1Wh, mV, mA, mW, mVA or mvar |
| 00000011 | 03 | Phase 3 | 0.1Wh, mV, mA, mW, mVA or mvar |
| 00000100 | 04 | Neutral | mA |
| 00000101 | 05 | Line 12 | mV |
| 00000110 | 06 | Line 23 | mV |
| 00000111 | 07 | Line 31 | mV |
| 00010000 | 10 | 3-Phase Imported Inductive Energy | 0.1VAh or 0.1varh |
| 00010001 | 11 | Phase 1 Imported Inductive Energy | 0.1VAh or 0.1varh |
| 00010010 | 12 | Phase 2 Imported Inductive Energy | 0.1VAh or 0.1varh |
| 00010011 | 13 | Phase 3 Imported Inductive Energy | 0.1VAh or 0.1varh |
| 00100000 | 20 | 3-Phase Exported Inductive Energy | 0.1VAh or 0.1varh |
| 00010001 | 21 | Phase 1 Exported Inductive Energy | 0.1VAh or 0.1varh |
| 00010010 | 22 | Phase 2 Exported Inductive Energy | 0.1VAh or 0.1varh |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| VIFE (BIN) | VIFE (HEX) | Description | Unit |
|---|---|---|---|
| 00010011 | 23 | Phase 3 Exported Inductive Energy | 0.1VAh or 0.1varh |
| 00100100 | 24 | 3-Phase Inductive Energy | 0.1VAh or 0.1varh |
| 00110000 | 30 | 3-Phase Imported Capacitive Energy | 0.1VAh or 0.1varh |
| 00110001 | 31 | Phase 1 Imported Capacitive Energy | 0.1VAh or 0.1varh |
| 00110010 | 32 | Phase 2 Imported Capacitive Energy | 0.1VAh or 0.1varh |
| 00110011 | 33 | Phase 3 Imported Capacitive Energy | 0.1VAh or 0.1varh |
| 01000000 | 40 | 3-Phase Exported Capacitive Energy | 0.1VAh or 0.1varh |
| 01000001 | 41 | Phase 1 Exported Capacitive Energy | 0.1VAh or 0.1varh |
| 01000010 | 42 | Phase 2 Exported Capacitive Energy | 0.1VAh or 0.1varh |
| 01000011 | 43 | Phase 3 Exported Capacitive Energy | 0.1VAh or 0.1varh |
| 01000100 | 44 | 3-Phase Capacitive Energy | 0.1VAh or 0.1varh |
| 01010000 | 50 | Frequency | mHz |
| 01010001 | 51 | Phase Order | Dimensionless |
| 01010010 | 52 | CT Value | Dimensionless |
| 01010011 | 53 | PT Value | Dimensionless |
| 01010100 | 54 | Actual Tariff | Dimensionless |
| 01010101 | 55 | Serial Number | Dimensionless |
| 01010110 | 56 | Model | Dimensionless |
| 01010111 | 57 | Type | Dimensionless |
| 01011000 | 58 | Firmware Release | Dimensionless |
| 01011001 | 59 | Hardware Release | Dimensionless |
| 01100000 | 60 | Wiring Mode | Dimensionless |
| 01100001 | 61 | Primary or Secondary Value | Dimensionless |
| 01100010 | 62 | Error Code | Dimensionless |
| 01100011 | 63 | Out Of Range | Dimensionless |
| 01100100 | 64 | FSA Value | A |
| 01110000 | 70 | Reset Counter | Dimensionless |
| 01110001 | 71 | Start Counter | Dimensionless |
| 01110010 | 72 | Stop Counter | Dimensionless |
| 01110011 | 73 | Partial Counter Status | Dimensionless |
| 10000000 | 80 | Imported Energy | 0.1Wh |
| 10000001 | 81 | Exported Energy | 0.1Wh |
| 10000010 | 82 | Partial | Dimensionless |
| 10000011 | 83 | Balance | Dimensionless |
| 10000100 | 84 | Power Factor | Dimensionless |
| 10010000 | 90 | Unit Volt-Ampere * $10^{-3}$ | mVA |
| 10010001 | 91 | Unit Volt-Ampere per hour * $10^{-1}$ | 0.1VAh |
| 10010010 | 92 | Unit Reactive Volt-Ampere * $10^{-3}$ | mvar |
| 10010011 | 93 | Unit Reactive Volt-Ampere per hour * $10^{-1}$ | 0.1varh |
| 10010100 | 94 | Unit Hertz (cycle per second) * $10^{-3}$ | MHz |

*Table 2.14 –Manufacturer Specific Value Information Field Extension Used*

If Bit No. 7 in the Specific Value Information Field Extension (VIFE) is set to 1, another VIFE Byte follows.
If Bit 7 is set to 0, the first Data Byte follows next.

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

# 3. Communication process

The M-BUS module accepts two kinds of transmission:

Send / Confirm → SND / CON

Request / Respond → REQ / RSP

A standard straight communication between M-BUS Master and M-BUS Slave is:




## 3.1 Send / confirm procedure

### 3.1.1 SND_NKE

This procedure serve to start up after an interruption or beginning of communication. If the Slave was selected for secondary addressing, it will be deselected.
The value of the frame count bit FCB is cleared in the Slave, i.e. it expects that the first telegram from a Master with FCV = 1, has the FCB = 1.
The Slave confirms a correct reception of the telegram with the single character acknowledge (E5h) or omits the answer if it didn't receive the telegram correctly.
Here follows the structure of SND_NKE command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 10 | Start character - short telegram |
| 2 | 1 | 40 | C Field |
| 3 | 1 | xx | A Field – Primary Address<br>00 – FA: Valid Primary Address<br>FB, FC: Reserved for Future Use<br>FD: Transmission is by Secondary Address<br>FE: Transmission to All M-BUS Slave in the System (everyone sends E5h)<br>FF: Transmission to All M-BUS Slave in the System (no one sends E5h) |
| 4 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 2 → byte 4) |
| 5 | 1 | 16 | Stop charcater |

*Table 3.1 – SND_NKE command Structure*

Answer of the Slave: E5h

### 3.1.2 SND_UD

This procedure is used to send user data to the M-BUS Slave. The Slave confirms a correct reception of the telegram with the single character acknowledge (E5h) or omits the answer if it didn't receive the telegram correctly.
Here follows the structure of the SND_UD commands used in this protocol.

#### 3.1.2.1 Set Primary Address

This action enables to set a new Primary Address in the Slave interface.
Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 06 | L-Field |
| 3 | 1 | 06 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 01 | DIF: 8 Bit Integer, 1 Byte |
| 9 | 1 | 7A | VIF: Set Primary Address |
| 10 | 1 | xx | Value: New Primary Address<br>Valid Range: 00 – FA (0 - 250)<br>Invalid Range: FB – FF |
| 11 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 10) |
| 12 | 1 | 16 | Stop character |

*Table 3.2 – SND_UD command: Set Primary Address*

Answer of the Slave: E5h

#### 3.1.2.2 Set Secondary Address

This action enables to set a new Secondary Address in the Slave interface.
The Secondary Address has this structure:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 – 4 | 4 | xx xx xx xx | Identification Number<br>Range : 00000000 - 99999999 |
| 5 – 6 | 2 | xx xx | Manufacturer ID<br>Range: 01 – FF, 01 - FF |
| 7 | 1 | xx | Version Number<br>Range: 01 - FF |
| 8 | 1 | 02 | Device Type Identification<br>02: Electricity |

*Table 3.3 – Secondary Address Structure*

Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 09 | L-Field |
| 3 | 1 | 09 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 0C | DIF: 8 digits BCD, 4 Byte |
| 9 | 1 | 79 | VIF: Set Secondary Address |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 10 | 1 | xx | Value: New Secondary Address digit 7 and 8<br>Range: 00 - 99 |
| 11 | 1 | xx | Value: New Secondary Address digit 5 and 6<br>Range: 00 – 99 |
| 12 | 1 | xx | Value: New Secondary Address digit 3 and 4<br>Range: 00 – 99 |
| 13 | 1 | xx | Value: New Secondary Address digit 1 and 2<br>Range: 00 - 99 |
| 14 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 13) |
| 15 | 1 | 16 | Stop character |

*Table 3.4 – SND_UD command: Set Secondary Address*

Answer of the Slave: E5h

#### 3.1.2.3 Set Baud Rate

This action allows to change the Baud Rate of the M-BUS Slave.
The Slave answers with single character acknowledgement (E5h) in the old baud rate. As soon as the ACK is transmitted, the Slave switches to the new baud rate.
To make sure that the Slave has properly changed its baud rate, the Master, within 2 minutes has to send a command to the Slave in the new baud rate. If the Slave doesn't send the ACK after x retry, the Master has to return to the old baud rate.
Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 03 | L-Field |
| 3 | 1 | 03 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00 - FF = 0 - 255) |
| 7 | 1 | xx | CI-Field: Set New Baud Rate<br>B8: Set Baud Rate to 300 baud<br>B9: Set Baud Rate to 600 baud<br>BA: Set Baud Rate to 1200 baud<br>BB: Set Baud Rate to 2400 baud<br>BC: Set Baud Rate to 4800 baud<br>BD: Set Baud Rate to 9600 baud<br>BE: Set Baud Rate to 19200 baud<br>BF: Set Baud Rate to 38400 baud |
| 8 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 7) |
| 9 | 1 | 16 | Stop character |

*Table 3.5 – SND_UD command*

Answer of the Slave: E5h



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

#### 3.1.2.4 Reset Total/Tariff 1/Tariff 2/All Energy Counters

This action is permitted only if the Energy Counters is "NO MID" or "yes reset" type.
Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 07 | L-Field |
| 3 | 1 | 07 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 01 | DIF: 8 Bit Integer, 1 Byte |
| 9 | 1 | FF | VIF followed by manufacturer specific VIFE |
| 10 | 1 | 70 | manufacturer specific VIFE: Reset Counter |
| 11 | 1 | xx | Value: Kind of Energy Counters<br>00: Reset Total Energy Counters<br>01: Reset Tariff 1 Energy Counters<br>02: Reset Tariff 2 Energy Counters<br>03: Reset ALL Energy Counters |
| 12 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 11) |
| 13 | 1 | 16 | Stop character |

*Table 3.6 – SND_UD command: Reset Active Energy Counters*

Answer of the Slave: E5h

#### 3.1.2.5 Reset Partial Energy Counters

Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 09 | L-Field |
| 3 | 1 | 09 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 01 | DIF: 8 Bit Integer, 1 Byte |
| 9 | 1 | FF | VIF followed by manufacturer specific VIFE |
| 10 | 1 | 82 | VIFE: Partial Counters |
| 11 | 1 | FF | VIFE followed by 3E specific VIFE |
| 12 | 1 | 70 | Manufacturer specific VIFE: Reset Counter |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 13 | 1 | xx | Value: Kind of Energy<br>00: Imported Active Energy<br>01: Exported Active Energy<br>02: Imported Inductive Apparent Energy<br>03: Exported Inductive Apparent Energy<br>04: Imported Capacitive Apparent Energy<br>05: Exported Capacitive Apparent Energy<br>06: Imported Inductive Reactive Energy<br>07: Exported Inductive Reactive Energy<br>08: Imported Capacitive Reactive Energy<br>09: Exported Capacitive Reactive Energy<br>0A: ALL partial counters |
| 14 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 13) |
| 15 | 1 | 16 | Stop character |

*Table 3.7 – SND_UD command: Reset Partial Energy Counter*

Answer of the Slave: E5h

**3.1.2.6 Start Partial Energy Counters**
Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 09 | L-Field |
| 3 | 1 | 09 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 01 | DIF: 8 Bit Integer, 1 Byte |
| 9 | 1 | FF | VIF followed by manufacturer specific VIFE |
| 10 | 1 | 82 | VIFE: Partial Counters |
| 11 | 1 | FF | VIFE followed by 3E specific VIFE |
| 12 | 1 | 71 | Manufacturer specific VIFE: Start Counter |
| 13 | 1 | xx | Value: Kind of Energy<br>00: Imported Active Energy<br>01: Exported Active Energy<br>02: Imported Inductive Apparent Energy<br>03: Exported Inductive Apparent Energy<br>04: Imported Capacitive Apparent Energy<br>05: Exported Capacitive Apparent Energy<br>06: Imported Inductive Reactive Energy<br>07: Exported Inductive Reactive Energy<br>08: Imported Capacitive Reactive Energy<br>09: Exported Capacitive Reactive Energy<br>0A: ALL partial counters |
| 14 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 13) |
| 15 | 1 | 16 | Stop character |

*Table 3.8 – SND_UD command: Start Partial Energy Counter*



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Answer of the Slave: E5h

### 3.1.2.7 Stop Partial Energy Counters

Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 09 | L-Field |
| 3 | 1 | 09 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 01 | DIF: 8 Bit Integer, 1 Byte |
| 9 | 1 | FF | VIF followed by manufacturer specific VIFE |
| 10 | 1 | 82 | VIFE: Partial Counters |
| 11 | 1 | FF | VIFE followed by 3E specific VIFE |
| 12 | 1 | 72 | Manufacturer specific VIFE: Stop Counter |
| 13 | 1 | xx | Value: Kind of Energy<br>00: Imported Active Energy<br>01: Exported Active Energy<br>02: Imported Inductive Apparent Energy<br>03: Exported Inductive Apparent Energy<br>04: Imported Capacitive Apparent Energy<br>05: Exported Capacitive Apparent Energy<br>06: Imported Inductive Reactive Energy<br>07: Exported Inductive Reactive Energy<br>08: Imported Capacitive Reactive Energy<br>09: Exported Capacitive Reactive Energy<br>0A: ALL partial counters |
| 14 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 13) |
| 15 | 1 | 16 | Stop character |

*Table 3.9 – SND_UD command: Stop Partial Energy Counter*

Answer of the Slave: E5h

### 3.1.2.8 Select a Slave Using Secondary Address

Here follows the command to select a Slave by Secondary Address:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 0B | L-Field |
| 3 | 1 | 0B | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | FD | A-Field, Primary Address = 253, i.e. take the secondary address |
| 7 | 1 | 52 | CI-Field |
| 8 – 15 | 8 | xx xx xx xx<br>xx xx xx xx | Secondary Address UD (See the relative paragraph) |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 16 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 15) |
| 17 | 1 | 16 | Stop character |

*Table 3.10 – SND_UD command: Select a slave Using Secondary Address*

Answer of the Slave: E5h



#### 3.1.2.9 Set Parameters Masks

This action allows to select the data to read-out from the Slave.
It can be possible read-out all data, choose the desired data or choose a default mask that include various kind of data.

READ-OUT ALL DATA
Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long query |
| 2 | 1 | 04 | L-Field |
| 3 | 1 | 04 | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 7F | DIF: Global Readout Request |
| 9 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 8) |
| 10 | 1 | 16 | Stop character |

*Table 3.11 – SND_UD command: Set Read-Out All Data Parameter Mask*

Answer of the Slave: E5h

READ-OUT DESIRED DATA
Here follows the command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long telegram |
| 2 | 1 | 0E | L-Field |
| 3 | 1 | 0E | L-Field Ripetition |
| 4 | 1 | 68 | Start character long query ripetition |
| 5 | 1 | 73 | C-Field SND_UD |
| 6 | 1 | xx | A-Field, Primary Address (00-FF = 0-255) |
| 7 | 1 | 51 | CI-Field |
| 8 | 1 | 07 | DIF: 64 Bit Integer, 8 Byte |
| 9 | 1 | FD | VIF: Followed by a standard VIFE |
| 10 | 1 | 0B | VIFE: Parameter Set Identification |
| 11 | 1 | "PS0" | Selected Parameter of Parameter Set 0 |
| 12 | 1 | "PS1" | Selected Parameter of Parameter Set 1 |
| 13 | 1 | "PS2" | Selected Parameter of Parameter Set 2 |
| 14 | 1 | "PS3" | Selected Parameter of Parameter Set 3 |
| 15 | 1 | "PS4" | Selected Parameter of Parameter Set 4 |
| 16 | 1 | "PS5" | Selected Parameter of Parameter Set 5 |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 17 | 1 | "PS6" | Selected Parameter of Parameter Set 6 |
| 18 | 1 | "PS7" | Selected Parameter of Parameter Set 7 |
| 19 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte 18) |
| 20 | 1 | 16 | Stop character |

*Table 3.12 – SND_UD command: Set Read-Out Desired Data Parameter Mask*

To set the Parameter Set to all M-BUS interface in the system is necessary use the primary address 255d (FFh) in the A-Field. In this case the M-BUS interface in the M-BUS system will not send an acknowledgement (no E5 will be sent by the M-BUS interfaces)

Answer of the Slave: E5h

See the Annex B for an example of a mask.

### 3.1.3 REQ_UD2

This procedure is used by the M-BUS Master to receive data to the M-BUS Slave. The Slave confirms a correct reception of the telegram with the RSP_UD answer or omits the answer if it didn't receive the telegram correctly.
The Slave sends the data requested by SND_UD command.
Here follows the structure of the REQ_UD2 command:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 10 | Start character short telegram |
| 2 | 1 | 7B / 5B | C-Field , Transmit Read-Out Data |
| 3 | 1 | xx | A Field – Primary Address<br>00 – FA: Valid Primary Address<br>FB, FC: Reserved for Future Use<br>FE: Transmission to All M-BUS Slave in the System (everyone sends E5h)<br>FF: Transmission to All M-BUS Slave in the System (no one sends E5h)<br>Out of Range: FD: Transmission is by Secondary Address |
| 4 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 2 → byte 3) |
| 5 | 1 | 16 | Stop character |

*Table 3.13 – REQ_UD2 command*

Answer of the Slave: RSP_UD

### 3.1.4 RSP_UD

This procedure is used by the M-BUS Slave to send the requested data to the M-BUS Master.
The behavior of the multi-frame answer is explained in Annex A.
Here follows the structure of the RSP_UD telegram:

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 1 | 1 | 68 | Start character long telegram |
| 2 | 1 | xx | L-Field |
| 3 | 1 | xx | L-Field Ripetition |
| 4 | 1 | 68 | Start character long telegram ripetition |
| 5 | 1 | 08 /18 | C-Field RSP_UD |
| 6 | 1 | xx | A-Field, Primary Address (00 - FA = 0 - 250) |
| 7 | 1 | 72 | CI-Field |
| 8 – 11 | 4 | xx xx xx xx | M-BUS Interface Identification Number |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| 12 – 13 | 2 | xx xx | Manufacturer's Mark |
| 14 | 1 | xx | Version Number of M-BUS Interface Firmware (00 – FF) |
| 15 | 1 | 02 | Medium: Electricity |
| 16 | 1 | xx | Access Number (00 – FF → 00) |
| 17 | 1 | xx | M-BUS Interface Status (see error flags par.) |
| 18 – 19 | 2 | 0000 | Signature (always 0000, i.e. not used) |
| 20 – YY | 0 – EA | xx...xx | Read-out Data Parametrised (see the following paragraphs) |
| YY + 1 | 1 | 0F / 1F | DIF: 0F = no more data; 1F = other data to send |
| YY + 2 | 1 | xx | CS Checksum, summed from C-Field to Selected Parameter of Parameter Set 19 (byte 5 → byte YY + 1) |
| YY + 3 | 1 | 16 | Stop character |

*Table 3.14 – RSP_UD command*

Here follows every possible Read-Out data, included in 20 – YY bytes of the RSP_UD table.

#### 3.1.4.1 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 00 | DIFE: Total |
| YY + 2 | 1 | 82 | VIF: Energy, 0.1Wh; Followed by VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 80 | VIFE: Imported Energy; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Total |

*Table 3.15 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Total*

#### 3.1.4.2 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 00 | DIFE: Total |
| YY + 2 | 1 | 82 | VIF: Energy, 0.1Wh; Followed by VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 81 | VIFE: Exported Energy; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Total |

*Table 3.16 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Total*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.3 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 – YY + 11 | 1 | 1x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Inductive<br>1: Phase 1 Imported Inductive<br>2: Phase 2 Imported Inductive<br>3: Phase 3 Imported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Total |

*Table 3.17 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Total*

### 3.1.4.4 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 2x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Inductive<br>1: Phase 1 Exported Inductive<br>2: Phase 2 Exported Inductive<br>3: Phase 3 Exported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Total |

*Table 3.18 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Total*

### 3.1.4.5 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 3x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Capacitive<br>1: Phase 1 Imported Capacitive<br>2: Phase 2 Imported Capacitive<br>3: Phase 3 Imported Capacitive |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Total |

*Table 3.19 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Total*



### 3.1.4.6 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 4x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Capacitive<br>1: Phase 1 Exported Capacitive<br>2: Phase 2 Exported Capacitive<br>3: Phase 3 Exported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Total |

*Table 3.20 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Total*

### 3.1.4.7 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 1x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Inductive<br>1: Phase 1 Imported Inductive<br>2: Phase 2 Imported Inductive<br>3: Phase 3 Imported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Total |

*Table 3.21 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Total*

### 3.1.4.8. 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 6 | 1 | 2x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Inductive<br>1: Phase 1 Exported Inductive<br>2: Phase 2 Exported Inductive<br>3: Phase 3 Exported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Total |

*Table 3.22 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Total*

### 3.1.4.9 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 3x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Capacitive<br>1: Phase 1 Imported Capacitive<br>2: Phase 2 Imported Capacitive<br>3: Phase 3 Imported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Total |

*Table 3.23 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Total*

### 3.1.4.10 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Total

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 4x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Capacitive<br>1: Phase 1 Exported Capacitive<br>2: Phase 2 Exported Capacitive<br>3: Phase 3 Exported Capacitive |
| YY + 7– YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Total |

*Table 3.24 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Total*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.11 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 10 | DIFE: Tariff 1 |
| YY + 2 | 1 | 82 | VIF: Energy, 0.1Wh; Followed by VIFE |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 80 | VIFE: Imported Energy; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Tariff 1 |

*Table 3.25 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Tariff 1*

### 3.1.4.12 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 10 | DIFE: Tariff 1 |
| YY + 2 | 1 | 82 | VIF: Energy, 0.1Wh; Followed by VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 81 | VIFE: Exported Energy; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Tariff 1 |

*Table 3.26 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Tariff 1*

### 3.1.4.13 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 – YY + 11 | 1 | 1x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Inductive<br>1: Phase 1 Imported Inductive<br>2: Phase 2 Imported Inductive<br>3: Phase 3 Imported Inductive |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Tariff 1 |

*Table 3.27 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Tariff 1*



### 3.1.4.14 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 2x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Inductive<br>1: Phase 1 Exported Inductive<br>2: Phase 2 Exported Inductive<br>3: Phase 3 Exported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Tariff 1 |

*Table 3.28 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Tariff 1*

### 3.1.4.15 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 3x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Capacitive<br>1: Phase 1 Imported Capacitive<br>2: Phase 2 Imported Capacitive<br>3: Phase 3 Imported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Tariff 1 |

*Table 3.29 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Tariff 1*

### 3.1.4.16 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |



Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 6 | 1 | 4x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Capacitive<br>1: Phase 1 Exported Capacitive<br>2: Phase 2 Exported Capacitive<br>3: Phase 3 Exported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Tariff 1 |

*Table 3.30 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Tariff 1*



### 3.1.4.17 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 1x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Inductive<br>1: Phase 1 Imported Inductive<br>2: Phase 2 Imported Inductive<br>3: Phase 3 Imported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Tariff 1 |

*Table 3.31 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Tariff 1*

### 3.1.4.18 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 2x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Inductive<br>1: Phase 1 Exported Inductive<br>2: Phase 2 Exported Inductive<br>3: Phase 3 Exported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Tariff 1 |

*Table 3.32 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Tariff 1*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.19 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 3x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Capacitive<br>1: Phase 1 Imported Capacitive<br>2: Phase 2 Imported Capacitive<br>3: Phase 3 Imported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Tariff 1 |

*Table 3.33 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Tariff 1*

### 3.1.4.20 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Tariff 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 90 | DIFE: Tariff 1; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 4x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Capacitive<br>1: Phase 1 Exported Capacitive<br>2: Phase 2 Exported Capacitive<br>3: Phase 3 Exported Capacitive |
| YY + 7– YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Tariff 1 |

*Table 3.34 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Tariff 1*

### 3.1.4.21 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 20 | DIFE: Tariff 2 |
| YY + 2 | 1 | 82 | VIF: Active Energy, 0.1Wh; Followed by VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 80 | VIFE: Imported Energy; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Tariff 2 |

*Table 3.35 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Active Energy, Tariff 2*



### 3.1.4.22 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 20 | DIFE: Tariff 2 |
| YY + 2 | 1 | 82 | VIF: Active Energy, 0.1Wh; Followed by VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 81 | VIFE: Exported Energy; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Tariff 2 |

*Table 3.36 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Active Energy, Tariff 2*

### 3.1.4.23 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 1x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Inductive<br>1: Phase 1 Imported Inductive<br>2: Phase 2 Imported Inductive<br>3: Phase 3 Imported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Tariff 2 |

*Table 3.37 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Apparent Energy, Tariff 2*

### 3.1.4.24 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 6 | 1 | 2x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Inductive<br>1: Phase 1 Exported Inductive<br>2: Phase 2 Exported Inductive<br>3: Phase 3 Exported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Tariff 2 |

*Table 3.38 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Apparent Energy, Tariff 2*

### 3.1.4.25 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 3x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Capacitive<br>1: Phase 1 Imported Capacitive<br>2: Phase 2 Imported Capacitive<br>3: Phase 3 Imported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Tariff 2 |

*Table 3.39 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Apparent Energy, Tariff 2*

### 3.1.4.26 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 4x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Capacitive<br>1: Phase 1 Exported Capacitive<br>2: Phase 2 Exported Capacitive<br>3: Phase 3 Exported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Tariff 2 |

*Table 3.40 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Apparent Energy, Tariff 2*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.27 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 1x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Inductive<br>1: Phase 1 Imported Inductive<br>2: Phase 2 Imported Inductive<br>3: Phase 3 Imported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Tariff 2 |

*Table 3.41 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Inductive Reactive Energy, Tariff 2*

### 3.1.4.28 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 2x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Inductive<br>1: Phase 1 Exported Inductive<br>2: Phase 2 Exported Inductive<br>3: Phase 3 Exported Inductive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Tariff 2 |

*Table 3.42 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Inductive Reactive Energy, Tariff 2*

### 3.1.4.29 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | MANUFACTURER specific VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 3x | MANUFACTURER specific VIFE:<br>0: 3-Phase Imported Capacitive<br>1: Phase 1 Imported Capacitive<br>2: Phase 2 Imported Capacitive<br>3: Phase 3 Imported Capacitive |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Tariff 2 |

*Table 3.43 – 3-Phase, Phase 1, Phase 2 and Phase 3 Imported Capacitive Reactive Energy, Tariff 2*



### 3.1.4.30 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Tariff 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | A0 | DIFE: Tariff 2; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | MANUFACTURER specific VIFE: Reactive Energy,0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 4x | MANUFACTURER specific VIFE:<br>0: 3-Phase Exported Capacitive<br>1: Phase 1 Exported Capacitive<br>2: Phase 2 Exported Capacitive<br>3: Phase 3 Exported Capacitive |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Tariff 2 |

Table 3.44 – 3-Phase, Phase 1, Phase 2 and Phase 3 Exported Capacitive Reactive Energy, Tariff 2

### 3.1.4.31 3-Phase, Phase 1, Phase 2 and Phase 3 Voltage

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 03 | DIF – 24 Bit Integer, 3 Byte |
| YY + 1 | 1 | FD | VIF: Followed by a standard VIFE |
| YY + 2 | 1 | C6 | VIFE: Instant Voltage (mV) followed by a VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 5 – YY + 7 | 3 | xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Voltage |

*Table 3.45 – 3-Phase, Phase 1, Phase 2 and Phase 3 Voltage*

### 3.1.4.32 Line 12, Line 23 and Line 31 Voltage

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 03 | DIF – 24 Bit Integer, 3 Byte |
| YY + 1 | 1 | FD | VIF: Followed by a standard VIFE |
| YY + 2 | 1 | C6 | VIFE: Instant Voltage (mV) followed by a VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 0x | MANUFACTURER specific VIFE:<br>5: Line 12<br>6: Line 23<br>7: Line 31 |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 5 – YY + 7 | 3 | xx xx xx | Value: Line 12, Line 23, Line 31 Voltage |

*Table 3.46 – Line 12. Line 23 and Line 31 Voltage*

#### 3.1.4.33 3-Phase, Phase 1, Phase 2, Phase 3 and Neutral Current

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 04 | DIF – 32 Bit Integer, 4 Byte |
| YY + 1 | 1 | FD | VIF: Followed by a standard VIFE |
| YY + 2 | 1 | D9 | VIFE: Current (mA) followed by a VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3<br>4: Neutral |
| YY + 5 – YY + 7 | 4 | xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2, Phase 3 and Nuetral Current |

*Table 3.47 – 3-Phase, Phase 1, Phase 2, Phase 3 and Neutral Current*

#### 3.1.4.34 Frequency

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 94 | MANUFACTURER specific VIFE: mHz |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 50 | MANUFACTURER specific VIFE: Frequency (mHz) |
| YY + 5 – YY + 6 | 2 | xx xx | Value: Frequency |

*Table 3.48 – Frequency*

#### 3.1.4.35 Phase Order

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 51 | MANUFACTURER specific VIFE: Phase Order |
| YY + 3 | 1 | xx | Value: Phase Order<br>00: No Phase Order<br>7B: 123<br>84: 132 |

*Table 3.49 – Phase Order*

#### 3.1.4.36 3-Phase, Phase 1, Phase 2 and Phase 3 Power Factor

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 2 | 1 | 84 | MANUFACTURER specific VIFE: Power Factor; Followed by VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 5 – YY + 6 | 2 | xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Power Factor |

*Table 3.50 – 3-Phase, Phase 1, Phase 2 and Phase 3 Power Factor*

### 3.1.4.37 3-Phase, Phase 1, Phase 2 and Phase 3 Active Power

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 06 | DIF – 48 Bit Integer, 6 Byte |
| YY + 1 | 1 | A8 | VIF: Active Power, mW; Followed by VIFE |
| YY + 2 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 3 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 4 – YY + 9 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Active Power |

*Table 3.51 – 3-Phase, Phase 1, Phase 2 and Phase 3 Active Power*

### 3.1.4.38 3-Phase, Phase 1, Phase 2 and Phase 3 Apparent Power

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Power |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 90 | VIFE: Apparent Power, mVa; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Apparent Power |

*Table 3.52 – 3-Phase, Phase 1, Phase 2 and Phase 3 Apparent Power*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.39 3-Phase, Phase 1, Phase 2 and Phase 3 Reactive Power

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Power |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 92 | VIFE: Reactive Power, mvar; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 0x | MANUFACTURER specific VIFE:<br>0: 3-Phase<br>1: Phase 1<br>2: Phase 2<br>3: Phase 3 |
| YY + 7 – YY + 12 | 6 | xx xx xx xx xx xx | Value: 3-Phase, Phase 1, Phase 2 and Phase 3 Reactive Power |

*Table 3.53 – 3-Phase, Phase 1, Phase 2 and Phase 3 Reactive Power*

### 3.1.4.40 3-Phase Imported and Exported Active Energy Partial

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 06 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 82 | VIF: Active Energy, 0.1Wh; Followed by VIFE |
| YY + 2 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 3 | 1 | 8x | MANUFACTURER specific VIFE:<br>0: Imported Energy<br>1: Exported Energy<br>Followed by VIFE |
| YY + 4 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 5 | 1 | 82 | MANUFACTURER specific VIFE: Partial; Followed by VIFE |
| YY + 6 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 7 | 1 | 00 | MANUFACTURER specific VIFE: 3-Phase |
| YY + 8 – YY + 13 | 6 | xx xx xx xx xx xx | Value: 3-Phase Imported and Exported Active Energy Partial |

*Table 3.54 – 3-Phase Imported and Exported Active Energy Partial*

### 3.1.4.41 3-Phase Imported and Exported Inductive Apparent Energy Partial

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 82 | MANUFACTURER specific VIFE: Partial; Followed by VIFE |
| YY + 7 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 8 | 1 | x0 | MANUFACTURER specific VIFE:<br>1: 3-Phase Imported Inductive<br>2: 3-Phase Exported Inductive |
| YY + 9 – YY + 14 | 6 | xx xx xx xx xx xx | Value: 3-Phase Imported and Exported Inductive Apparent Energy Partial |

*Table 3.55 – 3-Phase Imported and Exported Inductive Apparent Energy Partial*





Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.42 3-Phase Imported and Exported Capacitive Apparent Energy Partial

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 82 | MANUFACTURER specific VIFE: Partial; Followed by VIFE |
| YY + 7 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 8 | 1 | x0 | MANUFACTURER specific VIFE:<br>3: 3-Phase Imported Capacitive<br>4: 3-Phase Exported Capacitive |
| YY + 9 – YY + 14 | 6 | xx xx xx xx xx xx | Value: 3-Phase Imported and Exported Capacitive Apparent Energy Partial |

*Table 3.56 – 3-Phase Imported and Exported Capacitive Apparent Energy Partial*

### 3.1.4.43 3-Phase Imported and Exported Inductive Reactive Energy Partial

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 82 | MANUFACTURER specific VIFE: Partial; Followed by VIFE |
| YY + 7 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 8 | 1 | x0 | MANUFACTURER specific VIFE:<br>1: 3-Phase Imported Inductive<br>2: 3-Phase Exported Inductive |
| YY + 9 – YY + 14 | 6 | xx xx xx xx xx xx | Value: 3-Phase Imported and Exported Inductive Reactive Energy Partial |

*Table 3.57 – 3-Phase Imported and Exported Inductive Reactive Energy Partial*

### 3.1.4.44 3-Phase Imported and Exported Capacitive Reactive Energy Partial

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 82 | MANUFACTURER specific VIFE: Partial; Followed by VIFE |
| YY + 7 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 8 | 1 | x0 | MANUFACTURER specific VIFE:<br>3: 3-Phase Imported Inductive<br>4: 3-Phase Exported Inductive |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 9 – YY + 14 | 6 | xx xx xx xx xx xx | Value: 3-Phase Imported and Exported Capacitive Reactive Energy Partial |

*Table 3.58 – 3-Phase Imported and Exported Capacitive Reactive Energy Partial*



### 3.1.4.45 3-Phase Active Energy Balance

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 06 | DIF – 48 Bit Integer, 6 Byte |
| YY + 1 | 1 | 82 | VIF: Active Energy, 0.1Wh; Followed by VIFE |
| YY + 2 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 3 | 1 | 83 | MANUFACTURER specific VIFE: Balance; Followed by VIFE |
| YY + 4 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 7 | 1 | 00 | MANUFACTURER specific VIFE: 3-Phase |
| YY + 8 – YY + 13 | 6 | xx xx xx xx xx xx | Value: 3-Phase Active Energy Balance |

*Table 3.59 – 3-Phase Active Energy Balance*

### 3.1.4.46 3-Phase Inductive and Capacitive Apparent Energy Balance

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 40 | DIFE: Apparent Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 91 | VIFE: Apparent Energy, 0.1VAh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 83 | MANUFACTURER specific VIFE: Balance; Followed by VIFE |
| YY + 7 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 8 | 1 | x4 | MANUFACTURER specific VIFE:<br>2: 3-Phase Inductive<br>4: 3-Phase Capacitive |
| YY + 9 – YY + 14 | 6 | xx xx xx xx xx xx | Value: 3-Phase Inductive and Capacitive Apparent Energy Balance |

*Table 3.60 – 3-Phase Inductive and Capacitive Apparent Energy Balance*

### 3.1.4.47 3-Phase Inductive and Capacitive Reactive Energy Balance

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 86 | DIF – 48 Bit Integer, 6 Byte; Followed by DIFE |
| YY + 1 | 1 | 80 | DIFE: Total; Followed by DIFE |
| YY + 2 | 1 | 00 | DIFE: Reactive Value |
| YY + 3 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 4 | 1 | 93 | VIFE: Reactive Energy, 0.1varh; Followed by VIFE |
| YY + 5 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 6 | 1 | 83 | MANUFACTURER specific VIFE: Balance; Followed by VIFE |
| YY + 7 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 8 | 1 | x4 | MANUFACTURER specific VIFE:<br>2: 3-Phase Inductive<br>4: 3-Phase Capacitive |
| YY + 9 – YY + 14 | 6 | xx xx xx xx xx xx | Value: 3-Phase Inductive and Capacitive Reactive Energy Balance |

*Table 3.61 – 3-Phase Inductive and Capacitive Reactive Energy Balance*



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.48 CT Value

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 52 | MANUFACTURER specific VIFE: CT Value |
| YY + 3 – YY + 4 | 2 | xx xx | Value: CT Value |

*Table 3.62 – CT Value*

### 3.1.4.49 Actual Tariff

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 54 | MANUFACTURER specific VIFE: Actual Tariff |
| YY + 3 | 1 | xx | Value: Tariff<br>01: Tariff 1<br>02: Tariff 2 |

*Table 3.64 – Actual Tariff*

### 3.1.4.50 Serial Number

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 0D | DIF – Variable Length |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 55 | MANUFACTURER specific VIFE: Serial Number |
| YY + 3 – YY + 13 | 1 | 0A | Value: Serial Number<br>First Byte is LVAR: i.e. 10 ASCII char follows |
| YY + 4 – YY + 13 | 10 | xx xx xx xx xx<br>xx xx xx xx xx | Value: Serial Number (ASCII char), transmitted "Least significant byte first" |

*Table 3.65 – Serial Number*

### 3.1.4.51 Model

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 56 | MANUFACTURER specific VIFE: Model |
| YY + 3 | 1 | xx | Value: Model<br>02 = 46U, 3Phase,4Wire,6\|\|1Amp,USA<br>03 = 46E, 3Phase,4Wire,6\|\|1Amp,Europe<br>05 = 36U, 3Phase,3Wire,6\|\|1Amp,USA<br>06 = 36E, 3Phase,3Wire,6\|\|1Amp,Europe<br>07 = 48U, 3Phase,4Wire,80Amp,USA<br>08 = 48E, 3Phase,4Wire,80Amp,Europe<br>09 = 38U, 3Phase,3Wire,80Amp,USA<br>10 = 38E, 3Phase,3Wire,80Amp,Europe<br>11 = 18U, 1Phase,80Amp,USA<br>12 = 18E, 1Phase,80Amp,Europe |

*Table 3.66 – Model*

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.52 Type

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 57 | MANUFACTURER specific VIFE: Type |
| YY + 3 | 1 | xx | Value: Type<br>00: no MID, yes reset<br>01: no MID, no reset<br>02: MID<br>03: no MID, NO RESET, Wiring SET<br>04: no MID, NO RESET, DProfiles<br>05: MID, NO REACTIVE<br>06: no MID, NO RESET, DProfiles, no Wiring<br>07: MID, DProfile, Wiring<br>08: MID, DProfiled, no Wiring |

*Table 3.67 – Type*

### 3.1.4.53 Energy Counter Firmware Release 1

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 58 | MANUFACTURER specific VIFE: Firmware EC Release 1 |
| YY + 3 – YY + 4 | 2 | xx xx | Value: Firmware EC Release, e.g. xx.xx |

*Table 3.68 – Energy Counter Firmware Release 1*

### 3.1.4.54 Energy Counter Firmware Release 2

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 65 | MANUFACTURER specific VIFE: Firmware EC Release 2 |
| YY + 3 – YY + 4 | 2 | xx xx | Value: Firmware EC Release, e.g. xx.xx |

*Table 3.68 – Energy Counter Firmware Release 2*

### 3.1.4.55 Energy Counter Hardware Release

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 59 | MANUFACTURER specific VIFE: Hardware EC Release |
| YY + 3 – YY + 4 | 2 | xx xx | Value: Hardware EC Release, e.g. xx.xx |

*Table 3.69 – Energy Counter Hardware Release*



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

### 3.1.4.56 Primary or Secondary Value

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 61 | MANUFACTURER specific VIFE: Primary or Secondary Value |
| YY + 3 | 1 | xx | Value: Primary or Secondary Value<br>00: Primary Values<br>01: Secondary Values |

*Table 3.70 – Primary or Secondary Value*

### 3.1.4.57 Error Code

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 62 | MANUFACTURER specific VIFE: Error Code Value |
| YY + 3 | 1 | xx | Value: Error Code<br>00: No Error<br>01: Phase Sequence Error<br>02: Memory Error |

*Table 3.71 – Error Code*

### 3.1.4.58 Out Of Range

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 06 | DIF – 68 Bit Integer, 6 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 63 | MANUFACTURER specific VIFE: Out Of Range Value |
| YY + 3 | 1 | xx | Value: Out Of Range Frequency<br>00: No Out of Range<br>01: Frequency Out of Range |
| YY + 4 – YY + 5 | 2 | xx xx | Value: Out Of Range Low/High Phase Current<br>1 byte: 00 → FF – LORI2\|LORI1\|LORISYS\|HORIN\|HORI3\| HORI2\|HORI1\|HORISYS<br>2 byte: 00 → 03 – res\| res\| res\| res\| res\| res\|LORIN\|LORI3 |
| YY + 6 | 1 | xx | Value: Out of Range Low/High Line Voltage<br>00 → 3F – res\|res\|LORVL23\| LORVL13\| LORVL12\| HORVL23\| HORVL13\| HORVL12\| |
| YY + 7 | 1 | xx | Value: Out of Range Low/High Phase Voltage<br>00 → FF – LORV3N\|LORV2N\|LORV1N\|LORVSYS\| HORV3N\|HORV2N\|HORV1N\|HORVSYS\| |
| YY + 8 | 1 | 00 | Empty Byte |

*Table 3.72 – Out Of Range*

### 3.1.4.59 Fabrication Number

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 0C | DIF – 8 digit BCD, 4 Byte |
| YY + 1 | 1 | 78 | VIF: Fabrication No |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY + 2 – YY 5 | 4 | xx xx xx xx | Value: Fabrication Number |

*Table 3.73 –Fabrication Number*

### 3.1.4.60 M-BUS Module Firmware Release

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FD | VIF: Followed by a standard VIFE |
| YY + 2 | 1 | 0C | VIFE: Version |
| YY + 3 – YY 4 | 2 | xx xx | Value: Firmware Version Release |

*Table 3.74 – M-BUS Module Firmware Release*

### 3.1.4.61 M-BUS Module Hardware Release

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FD | VIF: Followed by a standard VIFE |
| YY + 2 | 1 | 0D | VIFE: Hardware Version |
| YY + 3 – YY 4 | 2 | xx xx | Value: Hardware Version Release |

*Table 3.75 – M-BUS Module Hardware Release*

### 3.1.4.62 Partial Counter Status

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 02 | DIF – 16 Bit Integer, 2 Byte |
| YY + 1 | 1 | FF | VIF followed by MANUFACTURER specific VIFE |
| YY + 2 | 1 | 73 | MANUFACTURER specific VIFE: Partial Counters Status |
| YY + 3 – YY + 4 | 2 | xx xx | Value: Out Of Range Low/High Phase Current<br>1 byte: -kvarhSYS-L-PAR \|+kvarhSYS-L-PAR \| -kVAhSYS-C-PAR \| +kVAhSYS-C-PAR \| -kVAhSYS-L-PAR \| +kVAhSYS-L-PAR \| -kWhSYS-PAR \| +kWhSYS-PAR<br>2 byte: res\| res\| res\| res\| res\| res\| -kvarhSYS-C-PAR \| +kvarhSYS-C-PAR |

*Table 3.76 – Partial Counter Status*

### 3.1.4.63 FSA Value

| Byte Nr. | Size (Byte) | Value (HEX) | Description |
|---|---|---|---|
| YY | 1 | 01 | DIF – 8 Bit Integer, 1 Byte |
| YY + 1 | 1 | FD | VIF: Followed by a standard VIFE |
| YY + 2 | 1 | DC | VIFE: Current (A) followed by a VIFE |
| YY + 3 | 1 | FF | VIFE followed by MANUFACTURER specific VIFE |
| YY + 5 | 1 | xx | Value: FSA Value<br>00: 1 A<br>01: 5 A<br>02: 80 A |

*Table 3.77 – FSA Value*

# ANNEX A

In case of single-frame RSP_UD answer from the Slave, the communication process is the following:

| MASTER | | SLAVE |
|---|---|---|
| SND_NKE | → | E5h |
| SND_UD | → | E5h |
| REQ_UD2 with C Field = 7Bh i.e. FCB = 1 & FCV = 1 | → | RSP_UD with C Field = 08h DIF = 0Fh as last data block |

This means that, if the FCB is handled (i.e. FCV = 1), when the RSP_UD answer has a single-frame of data, the Slave has to send a RSP_UD answer with the last data block egual to 0F.

In case of multi-frame RSP_UD answer from the Slave (for example 2 frames), the communication process is the following:

| MASTER | | SLAVE |
|---|---|---|
| SND_NKE | → | E5h |
| SND_UD | → | E5h |
| REQ_UD2 with C Field = 7Bh i.e. FCB = 1 & FCV = 1 | → | RSP_UD with C Field = 18h i.e. DFC = 1 DIF = 1Fh as last data block |
| REQ_UD2 with C Field = 5B i.e. FCB = 0 & FCV = 1 | → | RSP_UD with C Field = 08 i.e. DFC = 0 DIF = 0Fh as last data block |

This means that, if the FCB is handled (i.e. FCV = 1), when the RSP_UD answer has a single-frame of data, the Slave has to send a RSP_UD answer with the last data block egual to 0F.

# ANNEX B

Here follows the bit division of every Parameter Set byte:

| Bit Nr. | Bit Value | Measure Unit | Bit | Parameter Set |
|---|---|---|---|---|
| 1 | From Bit 39 To Bit 50 - Reactive (0b) or Apparent (1b) | - | xxxx xxx1b | PS0 |
| 2 | From Bit 51 To Bit 64 - Reactive (0b) or Apparent (1b) | - | xxxx xx1xb | |
| 3 | All Apparent and Reactive Energy Tariff 1 | 0.1varh & 0.1VAh | xxxx x1xxb | |
| 4 | All Apparent and Reactive Energy Total | 0.1varh & 0.1VAh | xxxx 1xxxb | |
| 5 | All Apparent and Reactive Energy Balance | 0.1varh & 0.1VAh | xxx1 xxxxb | |
| 6 | All Apparent and Reactive Energy Partial | 0.1varh & 0.1VAh | xx1x xxxxb | |
| 7 | All Apparent and Reactive Energy Tariff 2 | 0.1varh & 0.1VAh | x1xx xxxxb | |
| 8 | Phase 1, 2, 3, Sys Active Power | mW | 1xxx xxxxb | |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Bit Nr. | Bit Value | Measure Unit | Bit | Parameter Set |
|---|---|---|---|---|
| 9 | Phase 1, 2, 3, Sys Apparent Power | mVA | xxxx xxx1b | PS1 |
| 10 | Phase 1, 2, 3, Sys Reactive Power | mvar | xxxx xx1xb | |
| 11 | Phase 1, 2, 3, Sys Voltage | mV | xxxx x1xxb | |
| 12 | Line 12, 23, 31 Voltage | mV | xxxx 1xxxb | |
| 13 | Phase 1, 2, 3, N, Sys Current | mA | xxx1 xxxxb | |
| 14 | Phase 1, 2, 3, Sys Power Factor | - | xx1x xxxxb | |
| 15 | Frequency | mHz | x1xx xxxxb | |
| 16 | Phase Order | - | 1xxx xxxxb | |
| 17 | Actual Tariff | - | xxxx xxx1b | PS2 |
| 18 | CT Value, FSA Value | - | xxxx xx1xb | |
| 19 | Pri/Sec Value | - | xxxx x1xxb | |
| 20 | Error Code | - | xxxx 1xxxb | |
| 21 | Out Of Range | - | xxx1 xxxxb | |
| 22 | Partial Counter Status | - | xx1x xxxxb | |
| 23 | Serial Number, FW Release EC, HW Version EC, Model, Type | - | x1xx xxxxb | |
| 24 | FW Release, HW Version and Fabrication Number of M-BUS Module | - | 1xxx xxxxb | |
| 25 | Phase 1, 2, 3 Imported Active Energy Total | 0.1Wh | xxxx xxx1b | PS3 |
| 26 | 3-Phase Imported Active Energy Total | 0.1Wh | xxxx xx1xb | |
| 27 | Phase 1, 2, 3 Exported Active Energy Total | 0.1Wh | xxxx x1xxb | |
| 28 | 3-Phase Exported Active Energy Total | 0.1Wh | xxxx 1xxxb | |
| 29 | Phase 1, 2, 3 Imported Active Energy Tariff 1 | 0.1Wh | xxx1 xxxxb | |
| 30 | 3-Phase Imported Active Energy Tariff 1 | 0.1Wh | xx1x xxxxb | |
| 31 | Phase 1, 2, 3 Exported Active Energy Tariff 1 | 0.1Wh | x1xx xxxxb | |
| 32 | 3-Phase Exported Active Energy Tariff 1 | 0.1Wh | 1xxx xxxxb | |
| 33 | Phase 1, 2, 3 Imported Active Energy Tariff 2 | 0.1Wh | xxxx xxx1b | PS4 |
| 34 | 3-Phase Imported Active Energy Tariff 2 | 0.1Wh | xxxx xx1xb | |
| 35 | Phase 1, 2, 3 Exported Active Energy Tariff 2 | 0.1Wh | xxxx x1xxb | |
| 36 | 3-Phase Exported Active Energy Tariff 2 | 0.1Wh | xxxx 1xxxb | |
| 37 | All Active Energy Balance | 0.1Wh | xxx1 xxxxb | |
| 38 | All Active Energy Partial | 0.1Wh | xx1x xxxxb | |
| 39 | Phase 1, 2, 3 Imported Inductive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | x1xx xxxxb | |
| 40 | 3-Phase Imported Inductive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | 1xxx xxxxb | |
| 41 | Phase 1, 2, 3 Exported Inductive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx xxx1b | PS5 |
| 42 | 3-Phase Exported Inductive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx xx1xb | |
| 43 | Phase 1, 2, 3 Imported Inductive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx x1xxb | |
| 44 | 3-Phase Imported Inductive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx 1xxxb | |
| 45 | Phase 1, 2, 3 Exported Inductive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | xxx1 xxxxb | |
| 46 | 3-Phase Exported Inductive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | xx1x xxxxb | |
| 47 | Phase 1, 2, 3 Imported Inductive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | x1xx xxxxb | |
| 48 | 3-Phase Imported Inductive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | 1xxx xxxxb | |



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Bit Nr. | Bit Value | Measure Unit | Bit | Parameter Set |
|---|---|---|---|---|
| 49 | Phase 1, 2, 3 Exported Inductive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx xxx1b | PS6 |
| 50 | 3-Phase Exported Inductive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx xx1xb | |
| 51 | Phase 1, 2, 3 Imported Capacitive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx x1xxb | |
| 52 | 3-Phase Imported Capacitive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx 1xxxb | |
| 53 | Phase 1, 2, 3 Exported Capacitive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | xxx1 xxxxb | |
| 54 | 3-Phase Exported Capacitive Energy Total (Reactive or Apparent) | 0.1varh/0.1VAh | xx1x xxxxb | |
| 55 | Phase 1, 2, 3 Imported Capacitive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | x1xx xxxxb | |
| 56 | 3-Phase Imported Capacitive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | 1xxx xxxxb | |
| 57 | Phase 1, 2, 3 Exported Capacitive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx xxx1b | PS7 |
| 58 | 3-Phase Exported Capacitive Energy Tariff 1 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx xx1xb | |
| 59 | Phase 1, 2, 3 Imported Capacitive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx x1xxb | |
| 60 | 3-Phase Imported Capacitive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | xxxx 1xxxb | |
| 61 | Phase 1, 2, 3 Exported Capacitive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | xxx1 xxxxb | |
| 62 | 3-Phase Exported Capacitive Energy Tariff 2 (Reactive or Apparent) | 0.1varh/0.1VAh | xx1x xxxxb | |
| 63 | All Energy Balance (Reactive or Apparent) | 0.1varh/0.1VAh | x1xx xxxxb | |
| 64 | All Energy Partial (Reactive or Apparent) | 0.1varh/0.1VAh | 1xxx xxxxb | |

*Table B1 –Bit Division of Every Parameter Set Byte*

# ANNEX C

Here follows the structure of every default mask.

- Setting the Profile DEFAULT mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00000000 | 00 | From Bit 39 to Bit 50 Reactive Values has to be taken<br>From Bit 51 to Bit 64 Reactive Values has to be taken |
| PS1 | 00000000 | 00 | No One Value |
| PS2 | 00011111 | 1F | Actual Tariff<br>CT Value, FSA Value<br>Pri/Sec Value<br>Error Code<br>Out Of range |
| PS3 | 10100000 | A0 | 3-Phase Imported Active Energy Tariff 1<br>3-Phase Exported Active Energy Tariff 1 |
| PS4 | 00001010 | 0A | 3-Phase Imported Active Energy Tariff 2<br>3-Phase Exported Active Energy Tariff 2 |
| PS5 | 10101000 | A8 | 3-Phase Imported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 2 (Reactive from PS0 bit 0) |
| PS6 | 10000010 | 82 | 3-Phase Exported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>3-Phase Imported Capacitive Energy Tariff 1 (Reactive from PS0 bit 1) |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS7 | 00101010 | 2A | 3-Phase Exported Capacitive Energy Tariff 1 (Reactive from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Tariff 2 (Reactive from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Tariff 2 (Reactive from PS0 bit 1) |

*Table C1 – Default Mask Profile*



And so the Profile Default mask in HEX will be:

00 00 1F A0 0A A8 82 2A

- Setting the Profile ENERGY T1 e T2 mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00000000 | 00 | From Bit 39 to Bit 50 Reactive Values has to be taken<br>From Bit 51 to Bit 64 Reactive Values has to be taken |
| PS1 | 00000000 | 00 | No one value |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 11111111 | FF | Phase 1, 2, 3 Imported Active Energy Total<br>3-Phase Imported Active Energy Total<br>Phase 1, 2, 3 Exported Active Energy Total<br>3-Phase Exported Active Energy Total<br>Phase 1, 2, 3 Imported Active Energy Tariff 1<br>3-Phase Imported Active Energy Tariff 1<br>Phase 1, 2, 3 Exported Active Energy Tariff 1<br>3-Phase Exported Active Energy Tariff 1 |
| PS4 | 11001111 | CF | Phase 1, 2, 3 Imported Active Energy Tariff 2<br>3-Phase Imported Active Energy Tariff 2<br>Phase 1, 2, 3 Exported Active Energy Tariff 2<br>3-Phase Exported Active Energy Tariff 2<br>Phase 1, 2, 3 Imported Inductive Energy Total (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Total (Reactive from PS0 bit 0) |
| PS5 | 11111111 | FF | Phase 1, 2, 3 Exported Inductive Energy Total (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Total (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Exported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 2 (Reactive from PS0 bit 0) |
| PS6 | 11111111 | FF | Phase 1, 2, 3 Exported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Capacitive Energy Total (Reactive from PS0 bit 0)<br>3-Phase Imported Capacitive Energy Total (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Exported Capacitive Energy Total (Reactive from PS0 bit 0)<br>3-Phase Exported Capacitive Energy Total (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Capacitive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Imported Capacitive Energy Tariff 1 (Reactive from PS0 bit 0) |

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS7 | 00111111 | 3F | Phase 1, 2, 3 Exported Capacitive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Exported Capacitive Energy Tariff 1 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Capacitive Energy Tariff 2(Reactive from PS0 bit 0)<br>3-Phase Imported Capacitive Energy Tariff 2 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Exported Capacitive Energy Tariff 2 (Reactive from PS0 bit 0)<br>3-Phase Exported Capacitive Energy Tariff 2 (Reactive from PS0 bit 0) |

*Table C2 – Energy T1 & T2 Mask Profile*

And so the Profile Energy T1 e T2 mask in HEX will be:

00 00 18 FF CF FF FF 3F

- Setting the Profile TARIFF 1 mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00000100 | 04 | All Apparent and Reactive Energy Tariff 1 |
| PS1 | 00000000 | 00 | No one value |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 11110000 | F0 | Phase 1, 2, 3 Imported Active Energy Tariff 1<br>3-Phase Imported Active Energy Tariff 1<br>Phase 1, 2, 3 Exported Active Energy Tariff 1<br>3-Phase Exported Active Energy Tariff 1 |
| PS4 | 00000000 | 00 | No one value |
| PS5 | 00000000 | 00 | No one value |
| PS6 | 00000000 | 00 | No one value |
| PS7 | 00000000 | 00 | No one value |

*Table C3 – Tariff 1 Mask Profile*

And so the Profile Tariff 1 mask in HEX will be:

04 00 18 F0 00 00 00 00

- Setting the Profile TARIFF 2 mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 01000000 | 40 | All Apparent and Reactive Energy Tariff 2 |
| PS1 | 00000000 | 00 | No one value |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 00000000 | 00 | No one value |
| PS4 | 00001111 | 0F | Phase 1, 2, 3 Imported Active Energy Tariff 2<br>3-Phase Imported Active Energy Tariff 2<br>Phase 1, 2, 3 Exported Active Energy Tariff 2<br>3-Phase Exported Active Energy Tariff 2 |
| PS5 | 00000000 | 00 | No one value |
| PS6 | 00000000 | 00 | No one value |
| PS7 | 00000000 | 00 | No one value |

*Table C4 – Tariff 2 Mask Profile*



LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

And so the Profile Tariff 2 mask in HEX will be:

40 00 18 00 F0 00 00 00

- Setting the Profile TOTAL ENERGY mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00001000 | 08 | All Apparent and Reactive Energy Total |
| PS1 | 00000000 | 00 | No one value |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 00001111 | 0F | Phase 1, 2, 3 Imported Active Energy Total<br>3-Phase Imported Active Energy Total<br>Phase 1, 2, 3 Exported Active Energy Total<br>3-Phase Exported Active Energy Total |
| PS4 | 00000000 | 00 | No one value |
| PS5 | 00000000 | 00 | No one value |
| PS6 | 00000000 | 00 | No one value |
| PS7 | 00000000 | 00 | No one value |

*Table C5 – Total Energy Mask Profile*

And so the Profile Total Energy mask in HEX will be:

08 00 18 0F 00 00 00 00

- Setting the Profile REAL TIME mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 10010000 | 90 | All Apparent and Reactive Energy Balance<br>Phase 1, 2, 3 Active Power |
| PS1 | 11111111 | FF | Phase 1, 2, 3 Apparent Power<br>Phase 1, 2, 3 Reactive Power<br>Phase 1, 2, 3, Sys Voltage<br>Line 12, 23, 31 Voltage<br>Phase 1, 2, 3, N, Sys Current<br>Phase 1, 2, 3, Sys Power Factor<br>Frequency<br>Phase Order |
| PS2 | 11011111 | DF | Actual Tariff<br>CT Value, FSA Value<br>Pri/Sec Value<br>Error Code<br>Out Of range<br>Serial Number, FW Release EC, HW Version EC, Model, Type<br>FW Release and HW Version M-BUS Module |
| PS3 | 00000000 | 00 | No one value |
| PS4 | 00010000 | 10 | All Active Energy Balance |
| PS5 | 00000000 | 00 | No one value |
| PS6 | 00000000 | 00 | No one value |
| PS7 | 00000000 | 00 | No one value |

*Table C6 – Real Time Mask Profile*

And so the Profile Real Time mask in HEX will be:

90 FF DF 00 10 00 00 00

- Setting the Profile PARTIAL mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00100000 | 20 | All Apparent and Reactive Energy Partial |
| PS1 | 00000000 | 00 | No one value |
| PS2 | 00111000 | 38 | Error Code<br>Out Of range<br>Partial Counters Status |
| PS3 | 00000000 | 00 | No one value |
| PS4 | 00100000 | 20 | All Active Energy Partial |
| PS5 | 00000000 | 00 | No one value |
| PS6 | 00000000 | 00 | No one value |
| PS7 | 00000000 | 00 | No one value |

*Table C7 – Partial Mask Profile*

And so the Profile Partial mask in HEX will be:

20 00 38 00 20 00 00 00

- Setting the Profile ACTIVE mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 10000000 | 80 | Phase 1, 2, 3 Active Power |
| PS1 | 01000000 | 40 | Frequency |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 11111111 | FF | Phase 1, 2, 3 Imported Active Energy Total<br>3-Phase Imported Active Energy Total<br>Phase 1, 2, 3 Exported Active Energy Total<br>3-Phase Exported Active Energy Total<br>Phase 1, 2, 3 Imported Active Energy Tariff 1<br>3-Phase Imported Active Energy Tariff 1<br>Phase 1, 2, 3 Exported Active Energy Tariff 1<br>3-Phase Exported Active Energy Tariff 1 |
| PS4 | 00011111 | 1F | Phase 1, 2, 3 Imported Active Energy Tariff 2<br>3-Phase Imported Active Energy Tariff 2<br>Phase 1, 2, 3 Exported Active Energy Tariff 2<br>3-Phase Exported Active Energy Tariff 2<br>All Active Energy Balance |
| PS5 | 00000000 | 00 | No one value |
| PS6 | 00000000 | 00 | No one value |
| PS7 | 00000000 | 00 | No one value |

*Table C8 – Active Mask Profile*

And so the Profile Active mask in HEX will be:

80 40 18 FF 1F 00 00 00

- Setting the Profile REACTIVE mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00000000 | 00 | From Bit 39 to Bit 50 Reactive Values has to be taken<br>From Bit 51 to Bit 64 Reactive Values has to be taken |
| PS1 | 01000010 | 42 | Phase 1, 2, 3 Reactive Power<br>Frequency |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 00000000 | 00 | No one value |
| PS4 | 11000000 | C0 | Phase 1, 2, 3 Imported Inductive Energy Total (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Total (Reactive from PS0 bit 0) |
| PS5 | 11111111 | FF | Phase 1, 2, 3 Exported Inductive Energy Total (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Total (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Exported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 1 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 2 (Reactive from PS0 bit 0) |
| PS6 | 11111111 | FF | Phase 1, 2, 3 Exported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 2 (Reactive from PS0 bit 0)<br>Phase 1, 2, 3 Imported Capacitive Energy Total (Reactive from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Total (Reactive from PS0 bit 1)<br>Phase 1, 2, 3 Exported Capacitive Energy Total (Reactive from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Total (Reactive from PS0 bit 1)<br>Phase 1, 2, 3 Imported Capacitive Energy Tariff 1 (Reactive from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Tariff 1 (Reactive from PS0 bit 1) |
| PS7 | 01111111 | 7F | Phase 1, 2, 3 Exported Capacitive Energy Tariff 1 (Reactive from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Tariff 1 (Reactive from PS0 bit 1)<br>Phase 1, 2, 3 Imported Capacitive Energy Tariff 2 (Reactive from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Tariff 2 (Reactive from PS0 bit 1)<br>Phase 1, 2, 3 Exported Capacitive Energy Tariff 2 (Reactive from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Tariff 2 (Reactive from PS0 bit 1)<br>All Energy Balance (Reactive from PS0 bit 1) |

*Table C9 – Reactive Mask Profile*

And so the Profile Reactive mask in HEX will be:

00 42 18 00 C0 FF FF 7F

- Setting the Profile APPARENT mask:

| Parameter Set | Value (BIN) | Value (HEX) | Description |
|---|---|---|---|
| PS0 | 00000011 | 03 | From Bit 39 to Bit 50 Apparent Values has to be taken<br>From Bit 51 to Bit 64 Apparent Values has to be taken |
| PS1 | 01000001 | 41 | Phase 1, 2, 3 Apparent Power<br>Frequency |
| PS2 | 00011000 | 18 | Error Code<br>Out Of range |
| PS3 | 00000000 | 00 | No one value |
| PS4 | 11000000 | C0 | Phase 1, 2, 3 Imported Inductive Energy Total (Apparent from PS0 bit 0)<br>3-Phase Imported Inductive Energy Total (Apparent from PS0 bit 0) |
| PS5 | 11111111 | FF | Phase 1, 2, 3 Exported Inductive Energy Total (Apparent from PS0 bit 0)<br>3-Phase Exported Inductive Energy Total (Apparent from PS0 bit 0)<br>Phase 1, 2, 3 Imported Inductive Energy Tariff 1 (Apparent from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 1 (Apparent from PS0 bit 0)<br>Phase 1, 2, 3 Exported Inductive Energy Tariff 1 (Apparent from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 1 (Apparent from PS0 bit 0)<br>Phase 1, 2, 3 Imported Inductive Energy Tariff 2 (Apparent from PS0 bit 0)<br>3-Phase Imported Inductive Energy Tariff 2 (Apparent from PS0 bit 0) |
| PS6 | 11111111 | FF | Phase 1, 2, 3 Exported Inductive Energy Tariff 2 (Apparent from PS0 bit 0)<br>3-Phase Exported Inductive Energy Tariff 2 (Apparent from PS0 bit 0)<br>Phase 1, 2, 3 Imported Capacitive Energy Total (Apparent from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Total (Apparent from PS0 bit 1)<br>Phase 1, 2, 3 Exported Capacitive Energy Total (Apparent from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Total (Apparent from PS0 bit 1)<br>Phase 1, 2, 3 Imported Capacitive Energy Tariff 1 (Apparent from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Tariff 1 (Apparent from PS0 bit 1) |
| PS7 | 01111111 | 7F | Phase 1, 2, 3 Exported Capacitive Energy Tariff 1 (Apparent from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Tariff 1 (Apparent from PS0 bit 1)<br>Phase 1, 2, 3 Imported Capacitive Energy Tariff 2 (Apparent from PS0 bit 1)<br>3-Phase Imported Capacitive Energy Tariff 2 (Apparent from PS0 bit 1)<br>Phase 1, 2, 3 Exported Capacitive Energy Tariff 2 (Apparent from PS0 bit 1)<br>3-Phase Exported Capacitive Energy Tariff 2 (Apparent from PS0 bit 1)<br>All Energy Balance (Apparent from PS0 bit 1) |

*Table C10 – Apparent Mask Profile*

And so the Profile Apparent mask in HEX will be:

03 41 18 00 C0 FF FF 7F

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000

SENECA

azienda con sistema di gestione per la qualità certificato
ISO 9001:2008

**SENECA s.r.l.**
Via Austria, 26 - 35127 - PADOVA - ITALY
Tel. +39.049.8705355 - 8705359 - Fax +39.049.8706287
e-mail: info@seneca.it - www.seneca.it

LRI Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000