
EN

S20N1-KIT

CONNECTION BOARD FOR EXTERNAL BUTTONS AND LAMPS FOR BATCH CONTROLLER S20N1-1-ST AND S21N1-1-ST

To connect external buttons and lights to S20N1 or S21N1 batch controller, please use the appropriate S20N1-KIT connection board. Pease connect the S20N1-KIT board to the EXT rear socket with the flat cable supplied.
With the S20N1-KIT you can connect the 6 buttons (START, STOP, RESET, SEL, RIGHT ARROW and UP ARROW) and the 3 light indicators (START, STOP and RESET) directly on the card terminals.
The 6 buttons shall be N.O. (normally open) and voltage free (free contacts) and the 3 light indicators shall be 24V 2W. The light indicators are powered internally from the card.
Please follow the connections on the schematic below:



UNI EN ISO 9001
CERTIFICATE
Nr. 9115.SENE

SENECA s.r.l.
Via Austria, 26 – 35127
PADOVA - ITALY
Tel. +39.049.8705355 – 8705359 - 8705408
Fax +39.049.8706287
e-mail: info@seneca.it
www.seneca.it

Distribuída no Brasil pela LRI | vendas@lri.com.br | 51 2129-3000